

VIVIFLEX

Genova (I)

MANUALE DI PROCEDURA POST INSTALLAZIONE E MANUTENZIONE

IT

Rev. 1.0
Ottobre 2014

AVVERTENZE GENERALI

Dopo aver controllato l'integrità della confezione, se l'attuatore manifestasse malfunzionamenti o lavorasse in modo anomalo si raccomanda di non procedere con l'installazione e di contattare il rivenditore od il produttore.

Tutti gli interventi sull'attuatore e/o suoi componenti devono essere fatti esclusivamente da tecnici autorizzati e qualificati; il produttore non si assume alcuna responsabilità per interventi eseguiti da personale non legittimato.

Tutti gli attuatori di nostra produzione sono progettati in modo da non imporre all'utilizzatore finale una rilevante manutenzione periodica o straordinaria di particolare importanza.

In caso di installazione dell'attuatore in luoghi con condizioni particolarmente difficili ove grasso, sporco, sbalzi di temperatura, cicli di apertura e chiusura molto frequenti oppure in caso di variazioni del carico dovuti a vento forte o neve, è necessario procedere almeno ogni 6 mesi con il controllo dei gruppi di attuazione, con la pulizia della catena, con il controllo della tenuta e dell'integrità degli elementi di fissaggio quali staffe, viteria e guarnizioni nonché verificare eventuali deformazioni del serramento e dei cablaggi.

Se a seguito della verifica effettuata si riscontrassero anomalie o malfunzionamenti, si raccomanda di contattare il rivenditore od il produttore.

Tutte le parti interne quali ingranaggi, scheda elettronica e viti sono già state opportunamente trattate dal produttore in modo da assicurare all'attuatore un lavoro ottimale, si raccomanda quindi di non aprire o maneggiare tali parti in quanto molto delicate.

Tutte le catene in acciaio inossidabile non necessitano di alcuna manutenzione con grasso od altro prodotto perché già trattate dal produttore; è necessaria la sola pulizia periodica con un panno al fine di evitare che la stessa, durante i cicli di apertura e chiusura, trasporti all'interno corpi estranei che potrebbero causare malfunzionamenti o blocco dell'attuatore.

Si raccomanda, in caso fosse necessario sostituire staffe od altre parti di ricambio, l'utilizzo di pezzi originali acquistabili dal rivenditore o direttamente dal produttore (in caso di acquisto diretto degli attuatori).

Per l'acquisto di tali parti è necessario fornire il modello dell'attuatore, l'anno di produzione ed il numero di serie.

SMALTIMENTO

A fine periodo, l'attuatore deve essere smaltito secondo la legislazione vigente nel paese di utilizzo e nel rispetto delle norme in vigore inerenti il rispetto ambientale.

E' obbligatorio smontare l'attuatore differenziando le varie parti e componenti dello stesso (scheda elettronica, parti in plastica, alluminio, ecc.)

VIVIFLEX

Genova (I)

POST INTALLATION AND MAINTENANCE MANUAL

EN

Rev. 1.0
Ottobre 2014

GENERAL INSTRUCTIONS

After checking the integrity of the pack, if any anomaly or malfunction should be detected it is recommended not to install the actuator and advise the reseller or the producer.

All interventions on actuator and/or its components must be done by authorized and qualified technicians; the producer not assumes any responsibility regarding interventions performed by not legitimated personnel.

All the actuators produced by us are designed for not to oblige the final user to a relevant periodic or extraordinary maintenance of particular importance.

In particular conditions or heavy-duty installations where grease, dirty, changes of temperature, frequent open/close cycles or in case of big load variations due to strong wind or snow it is necessary at least every 6 months proceed to a check of the actuator assembly components, to clean the chain and to check that the fixing systems are tight as brackets, screws, seals as well as verify any deformations of the frame and cables.

If any malfunctions is detected after check, it is recommended to contact the reseller or the producer.

All internal parts as gears, electric board, screws have been already treated by our production staff to ensure the right work of the actuator, we recommend not to open or handle the inside parts of the motor because are very delicates.

All stainless steel chains don't need any maintenance with grease or other products because have already had their proper treatment by producer; they have only to be cleaned periodically with a lint-free cloth just to avoid that the same, during the open/close cycles, doesn't carry anything inside that can cause malfunctions or stop of the motor.

It is recommended, in case of it is necessary replace brackets or other spare parts, to use originals ones buyable from the reseller or directly from the producer (in case of direct purchase of the actuators).

To purchase these parts it is necessary provide the model of the actuator, the year of production and the serial number.

DEMOLITION

At the end of its lifetime, the actuator must to be disposed of in compliance with the laws in force on the Country of use regarding the environment protection.

It is mandatory to disassemble the actuator differentiate the parts and components of the same (electric board, plastic parts, aluminium, etc.).